

2011-2016 Ford Super Duty 6.7L Power Stroke Big Line Kit



1. Make sure that the engine is cool when performing this installation.
2. Disconnect the battery cables from the negative posts of both batteries.
3. Using a flat head screwdriver, release the blue fuel line retaining clip on the under hood fuel filter housing.
 - **Note:** Take caution when removing this line as it may be under pressure.
4. Release the green fuel line retaining clip on the other end of the line and remove the fuel line from the truck.
5. Thread the fuel pressure sensor onto the new fuel line adapter and tighten.
6. Install the fuel line adapter onto the truck in the factory location, ensuring that the connectors are seated fully by pressing the connector on until a click sound is heard.
7. Plug in the gauge sensor harness into the fuel pressure sensor and secure the wire using zip ties.
8. Reconnect the battery cables to the negative posts of each battery.
9. Start the truck and check for any leaks.